

TAIWAN EXCELLENCE 2023
Everyday Excellence

YouBike won the Taiwan Excellence Award!

Welcome to contact us
E-mail: JamesHuang2@youbike.com.tw
Website: https://www.youbike.com.tw

Check before you ride

Some Checking bike procedure

5 Main Key Points

- Brake**
Use both hands to gradually adjust the brakes.
- Tire Pressure**
Please check the tire pressure on both front and back wheel.
- Light**
Check if the front and rear lights are functional.
- Saddle height**
Adjust the height to the suitable place for you.
The correct scale of saddle is
- Do not rent the bike that its saddle is turned backwards around**
It means this bike is faulty and waits for repair by our maintenance.

How to adjust the height of saddle?

Some Adjusting bike feature

- Press up pull rod 2. Adjust height 3. Hear sound 4. Safe ride
- Press up the pull rod and adjust the saddle height.
- Release the pull rod and hear the KA sound.
- Make sure the saddle is stable.

YouBike 2.0 Instructional videos
YouBike 2.0E Instructional videos

How to use lock?

Some Locking bike steps

Lock

Turn right the bike head and insert the lock-head

- Turning the bike head to right.
- Aligning the lock holes between up and down.
- Taking the lock-head off the basket.
- Inserting the lock-head all the way into the lock holes. You need to go through the front wheel and across to the back.
- When the screen shows lock successfully, it means you have already locked the bike.

Unlock

Click button to unlock

Tap IC card to unlock

- Press Tap IC Card button to make the bike.
- Tap the card on the sensor zone and screen shows Remove the ready lock when completed.
- Take the lock-head out of the lock holes.
- When the screen shows Happy Ride, it means you have already unlocked the bike.

Scan QR code to unlock

- Press Scan QR Code button to enable the bike.
- Use the YouBike 2.0 APP and press the Scan QR Code button on the screen. Scan QR code or enter verification code to unlock the bike. If you cannot scan QR code when you encounter glass, enter verification code to unlock it.
- Take the lock-head out of the lock holes.
- When the screen shows Happy Ride, it means you have already unlocked the bike.

YouBike 2.0 system
2 Types of YouBike for you to ride!

YouBike 2.0
YouBike 2.0E
Shared dock

Rent with IC card

Some Rent/Returning bike procedure

Rent with IC card

- Press button 2 Tap card 3 Ride
- Press Tap IC Card button to enable the bike.
- Tap your card on the sensor zone.
- Screen shows Pull the bike backwards.
- Pull back on the handlebars with both hands to release the bike.

Return with IC card

Return to the dock 2.2 with IC card

- Align the head of your bike to the public road.
- Align the side lock to its docking part, then push the bike all the way in.
- Screen shows Tap the IC Card.
- Tap the card on the sensor zone and screen shows Charge and Station when completed.

Rent with scan QR code

Some Rent/Returning bike procedure

Rent with scan QR code

- Press button 2 Tap card 3 Ride
- Press Scan QR code button to enable the bike.
- Use the YouBike 2.0 APP and press the Scan QR code button on the screen. Scan QR code or enter verification code to unlock the bike. If you cannot scan QR code when you encounter glass, enter verification code to unlock it.
- Screen shows Pull the bike backwards, and pull back on the handlebars with both hands to release the bike.

Compatible official YouBike 2.0 APP

Return with scan QR code

- Press button 2 Tap card 3 Ride
- Align the head of your bike to the public road.
- Align the side lock to its docking part, then push the bike all the way in.
- Screen shows Thank you when completed.

YouBike 2.0 system features

2 Types of YouBike

Same Member account
Register your card for renting YouBike 2.0 and 2.0E.

Shared dock
Able to park on YouBike 2.0 dock for both types.

Multiple Rental tools
Smart Card (PK15) Scan QR code (Use your smartphone to scan QR code and set up the payment method).

Exclusive App (YouBike 2.0 APP)
When APP shows "lighting mode" on the left top of the station, please there are YouBike 2.0E available.

Smart Screen Battery Notification
Display screen on the bike. No Electric Power Assist. Check the Battery Notification on the screen and follow the procedure.

Electric Power Assist
Configure with high capacity lithium battery. Available to 100-150 kilometer maximum on the flat road with full battery. This electric power assist mode need not be charged per day.

YouBike ESG with You!

E E-power available
S Safety moving
G Greater city Greater journey

u-bike

YouBike 2.0 system
2 Types of YouBike for you to ride!

Standard bike

Shared bike

IC Card Rent with IC card
Scan QR code to rent the bike

Rent with IC card
Please follow the steps:

1. Press the IC Card button to unlock the bike.
2. Tap your card on the sensor.
3. Remove the front wheel lock.
4. Push on the handlebar with your hand to activate the bike.

Return with IC card
Return to the dock (QR code)

1. Align the head of your bike to the QR code.
2. Apply the lock on the handlebar. Please do not adjust the seat.
3. Remove the front wheel lock.
4. Tap the QR code on the sensor. The QR code will be activated when the bike is returned.

QR Code Rent with scan QR code
Scan QR code to rent the bike

Rent with scan QR code
Please follow the steps:

1. Press the QR code button to unlock the bike.
2. Scan the QR code on the QR code sensor. Scan QR code in white rectangular code to unlock the bike.
3. Remove the front wheel lock.
4. Push on the handlebar with your hand to activate the bike.

Return with scan QR code
Return to the dock (QR code)

1. Align the head of your bike to the QR code.
2. Apply the lock on the handlebar. Please do not adjust the seat.
3. Remove the front wheel lock.
4. Tap the QR code on the sensor. The QR code will be activated when the bike is returned.

YouBike 2.0 system features
2 Types of YouBike

<p>Same Member account</p> <p>Register your card for renting YouBike 2.0 and U-Bike.</p>	<p>Shared dock</p> <p>Actively join in YouBike 2.0 dock for more spots.</p>
<p>Multiple Rental tools</p> <p>Assigned QR code</p> <p>Scan QR code to rent the bike.</p>	<p>Exclusive App (YouBike 2.0 APP)</p> <p>Check your status, "locking" status on the app. Please do not use the app for other purposes.</p>
<p>Smart Screen Battery notification</p> <p>Check the battery status on the screen.</p>	<p>Electric Power Assist</p> <p>Configure with high capacity battery. The battery will be fully charged in 1.5 hours.</p>

YouBike ESG with You!

- E** E-power available
- S** Safety moving
- G** Greater city Greater journey

TAIWAN EXCELLENCE 2023
Empowering Excellence

(YouBike won the Taiwan Excellence Award)

Welcome to contact us
E-mail: James.kuang@youbike.com.tw
Website: <https://www.youbike.com.tw>

Check before you ride
Scan QR code to rent the bike

3-Min Top Rules

1. **Brake**
Use both hands to gradually adjust the brake.
2. **Tire Pressure**
Please check the tire pressure on both front and back wheel.
3. **Light**
Check if the front and rear lights are functional.
4. **Saddle height**
Adjust the height to the suitable place for you.
5. **Do not rent the bike that its saddle is turned backwards around.**
It means this bike is faulty and waits for repair by our maintenance.

How to adjust the height of saddle?
Scan QR code to rent the bike

1. Press up pull rod.
2. Adjust height.
3. Hear sound!
4. Safe ride!

YouBike 2.0 Instructional videos

QR code for YouBike 2.0 Instructional videos

How to use lock?
Scan QR code to rent the bike

Lock
Turn right the bike head and insert the lock head.

1. Bring up the lock to top.
2. Bring up the lock and adjust the lock.
3. Bring up the lock and adjust the lock.
4. Bring up the lock and adjust the lock.
5. Bring up the lock and adjust the lock.

Unlock
Click buttons to unlock

Tap IC card to unlock

1. Press the IC Card button to unlock the bike.
2. Perform an operation and activation please. Remove the QR code when you complete.

Scan QR code to unlock

1. Press the QR Code button to unlock the bike.
2. Use the YouBike 2.0 APP to unlock the bike. Please do not use the app for other purposes.
3. Tap the lock head out of the lock hole.
4. When the screen shows "Please Wait", it means your bike already activated the bike.

TAIWAN EXCELLENCE 2023
Everjoyful Excellence

YouBike won the Taiwan Excellence Award /

Welcome to contact us
E-mail : JamesHuang2@youbike.com.tw
Website : <https://www.YouBike.com.tw>

Check before you ride

Same Checking bike procedure

5 Main Key Points

- Brake**
Use both hands to gradually adjust the brakes.
- Tire Pressure**
Please check the tire pressure on both front and back wheel.
- Light**
Check if the front and rear lights are functional.
- Saddle height**
Adjust the height to the suitable place for you.

The lowest scale of saddle is 15.
- Do not rent the bike that its saddle is turned backwards around.**
It means this bike is faulty and waits for repair by our maintenance.

How to adjust the height of saddle?

Same Adjusting bike features

- Press up pull rod
- Adjust height
- Hear sound
- Safe ride

- Press up the pull rod and adjust the saddle height.
- Release the pull rod and hear the KA sound.
- Make sure the saddle is stable.

YouBike 2.0 Instructional videos
YouBike 2.0E Instructional videos

How to use lock?

Same Locking bike steps

Lock

Turn right the bike head and insert the lock-head

- Turning the bike head to right.
- Aiming the lock holes between up and down.
- Taking the lock-head off the basket.
- Inserting the lock-head all the way into two lock holes. No need to go through the front wheel and no key to help.
- When the screen shows Lock successfully, it means you have already locked the bike.

Unlock

Click button to unlock

Tap IC card to unlock

- Press Tap IC Card button to awake the bike.
- Tap the card on the sensor zone and screen shows. Removes the mobile lock when completed.
- Take the lock-head out of the lock holes.
- When the screen shows Enjoy Ride, it means you have already unlocked the bike.

Scan QR code to unlock

- Press Scan QR Code button to awake the bike.
- Use the YouBike 2.0 APP and press the Scan QR Code button on the screen. Scan QR code or enter verification code to unlock the bike. (If you cannot scan QR code when you encounter glare, enter verification code to unlock.)
- Take the lock-head out of the lock holes.
- When the screen shows Enjoy Ride, it means you have already unlocked the bike.

